



















Pin-tura®

Installation Instructions

What's in the Box	①Charging board(21.65in*21.65in)		③Power adapter*1		④Product bracket*2		⑤Lag bolts ¼" and 3" long*3	
								
	②Wall bracket*1		⑥Pan head screw M3*12 (6pcs)		⑦Flat screw M3*12 (4pcs)		⑧Foot*2	
								
			⑩Power cord*1		⑪PAD			
					 10.1"Pad*1+13.3"Pad*1 (Config.1)			
					 10.1"Pad*2+13.3"Pad*2 (Config.2)			
You will need	a. Pencil		c. Drill		e. Stud Finder		f. Lag bolt driver	
								
	b. Level		d. 1/8"Drill bit				g. Socket screwdriver	
								

Installation Method

1


*Due to the weight of the unit, we strongly recommend securing the bracket into the studs.


Step 1


Step 2

Step 3

Wooden Stud










*You will need: pencil, level, drill and 1/8"drill bit, stud finder, Lag bolt driver

2


Wall




 X3

 c

+

 g


or


 f

*Tighten using a drill/impact driver with a lag bolt or a wrench.

3

Install the product brackets and foots, and connect power cord.






④ X2

⑥ X2 ⑦ X4 ⑧ X2


4

Align then shift left to secure




5

Plug in the board and place the tablets on the red lights.




The red positioning lights will light for 7 seconds.



6


Hover the tablet close to the center of the board to re-light the red positioning lights.




7

Do not let go of the tablet until:

- It is magnetically fixed to the board.
- It is powered on.





Do Not Drop



Splicing method

1






④ X2


⑥ X12 ⑦ X4 ⑧ X4

⑨ X2



③ When connecting 5-16 tablets, please purchase another 19V 10.66A adapter.

2



To find the operation manual please visit:
<http://www.austinelec.com/english/ser/ser1.aspx>